

- Access options for the current activity or selection.

②③ **Color buttons**

- **BD:** Select tasks or options.

②④ **HDMI**

- Select the video resolution of HDMI output.

②⑤ **REPEAT**

- Select repeat play or shuffle play.

## 3 Connect

Make the following connections to use this product.

**Basic connections:**

- Video
- Audio
- Power

**Optional connections:**

- Route audio to other devices
  - HDMI-compliant AV receiver/amplifier
  - Multi-channel AV amplifier/receiver
  - Digital AV amplifier/receiver
  - Analog stereo system
- USB device
- LAN (network)

**Note**

- Refer to the type plate at the back or bottom of the product for identification and supply ratings.
- Before you make or change any connections, ensure that all devices are disconnected from the power outlet.
- Different types of connectors can be used to connect this product, depending on availability and your needs. A comprehensive interactive guide to help you connect your product is available at [www.connectivityguide.philips.com](http://www.connectivityguide.philips.com).

### Connect video/audio cables

Connect this product to TV to view disc play.


Select the best video connection that the TV can support.

- **Option 1:** Connect to the HDMI jack (for a HDMI, DVI or HDCP-compliant TV).
- **Option 2:** Connect to the component video jacks (for a standard TV or Progressive Scan TV).
- **Option 3:** Connect to the composite video jack (for a standard TV).

**Note**

- You must connect this product directly to a TV.

### Option 1: Connect to the HDMI jack




- 1 Connect an HDMI cable (not supplied) to:
  - the **HDMI** jack on this product.
  - the HDMI input jack on the TV.

**Tip**

- If the TV has a DVI connector only, connect via an HDMI/DVI adaptor. Connect an audio cable for sound output.
- You can optimize the video output. Press the **HDMI** button repeatedly to select the best resolution the TV can support.
- If this product connects to a TV compatible with 1080p or 1080p/24Hz, Philips recommends HDMI category 2 cable, also known as High Speed HDMI cable, for optimal video and audio output.
- To play the digital video images of a BD-video or DVD-video via an HDMI connection, it is necessary that both this product and the display device (or an AV receiver/amplifier) support a copyright protection system called HDCP (high-bandwidth digital content protection system).
- This type of connection provides best picture quality.

### Option 2: Connect to the component video jack



- 1 Connect the component video cables (not supplied) to:
  - the **Y Pb/Cb Pr/Cr** jacks on this product.