

Panasonic

US Consumer Models

2012 Models : ST50 / GT50 / VT50

2011 Models : X3 / S30 / ST30 / GT30 / VT30

2010 Models : X24 / C2 / U2 / S2 / G20 / G25 / GT20 / GT25 / VT20 / VT25

- Press and hold the {VOL -} button **ON THE PLASMA TV**.
- Then press the {INFO} button on the remote control 3 times.
- "Start Adjustment Menu" message will be displayed followed by the Service Menu after few seconds.

- **ADJUST** {Picture Adjustment}
- **WB-ADJUST** {White Balance Adjustment}
- **OPTION** {Option Setting}
- **V-SUS** {V-SUS Adjustment}
- **AGING**
- **SRV-TOOL** {Service Tool}

{1} & {2} buttons move through options

Press the {2} button once to select "SRV-TOOL".

Then press the {OK} button to access it.

Using the cursor keys, highlight the right side of the last item "PTCT:00.00.00.00.00":

SRV-TOOL	
TD2Microde: 81c0000f	
Flash ROM: 20-227E	
PTCT:00.00.00.00.00	<<< Highlight Here >>>

Then press and hold the {MUTE} button for 3 seconds.

Time and Count will be displayed in red color:

SRV-TOOL	
TD2Microde: 81c0000f	
Flash ROM: 20-227E	
PTCT:00.00.00.00.00	Time 00120:35 Count 25

__TIME = Hours : Minutes of operation.

COUNT = Times the Plasma was powered on.

To exit, unplug the power cable.

WARNING BY BRUZZI: The {VOL+} and {VOL-} buttons are used to change values while in the Service Menu. Make sure not to touch those buttons when navigating menus / sub-menus.